

INSTALLATION GUIDE: DIGITALLY PRINTED UNDER ICE LOGO

1

Measure for proper placement of the under ice logo on the ice. Logos with multiple panels will have 1.5" overlap unless specified.



2

Place the logo in the desired area then spray a thin layer of water over the logo to begin setting it into the ice.



3

Go over the logo with a roller to flatten the corners and edges and to remove any air pockets.



4

Lightly spray over the entire logo with water to create a frozen layer to keep the logo flat and ready for ice installation.



PLEASE CONTACT US AT 603-664-7174 WITH ANY QUESTIONS.

223 Drake Hill Road Strafford, NH 03884 | amigraphics.com